

IMPORTANT

- **Cleaning and maintaining the units is critical to avoid bacteria growth**
- **Not cleaning and maintaining the units can actually contribute to bacteria growth**
- **This unit should not be used for potable purposes (drinking water, cooking, ice making, brushing teeth) if MadiDrops are not added**
- **The filter disks and MadiDrop tablets should be replaced by: _____**

MADIDROP+ INSTRUCTIONS

1. Remove the top bucket.
2. Remove and clean the filter using a chlorine solution. Use soft side of Scotch-Brite sponge to remove dirt and scum from top of filter disk. Also remove any sediment or scum from bottom of top bucket.
3. Place MadiDrop+ into the lower bucket.
4. Reassemble the unit and add water to the top bucket.

REPLACEMENT FREQUENCY

- If you use 5 gallons of water per day, the MadiDrop+ should last for 12 months.
- However, we recommend replacing the MadiDrop+ at the same time as the disk filter (every 6-12 months), since it is easier to remember to replace both at the same time.
- **The Stacked Bucket system should not be used without the MadiDrop+.**

DAILY USE

- Feel free to fill the top bucket each night before bed. Water stored in the lower bucket overnight will be not be able to regrow bacteria if the MadiDrop+ has been added.

REPLACEMENT PARTS

Disk Filter Replacement

Visit website for factory in India
"Product Inquiries" tab

[See link at bottom of page](#)

Geet Chandak is the manager of the Imerys factory. Please contact Geet for filter replacement.

Geet Chandak

Tel. +91 22 2610 3358

drinkingwaterfiltration.AP@imerys.com

Note that buying filters in bulk is likely to be less expensive (between \$6.50 and \$8.00 per filter) when 100 or more are purchased at a time, excluding shipping.

Water Tap Replacement

Search "Tomlinson Spigot
Water Crock Replacement
Spigot Faucet Dispenser
ALMOND Valve"

on Ebay for water tap
replacement



tomlinson

MadiDrop+ Replacement

Information on
procuring MadiDrops is
available at:

[www.madidrop.com/
buy](http://www.madidrop.com/buy)

